


KW Trams

KW 022b Liverpool Twin Staircase cars 577-582 Later

Parts




Contents


1. Tram side	x2
2. Truck side	x2
3. Stairs	x2
4. Long step	x2
5. Short step	x2
6. Dash panel	x2
7. Upper sides	x2
8. Upper vestibules	x2
9. Long platform	x2
10. Upper floor 1/2	x2
11. Lower deck bulkhead	x2
12. Life guard	x2
13. Life tray	x2
14. Controller	x2
15. Short platform	x2
16. Handbrake	x2
17. Handbrake wheel	x2
18. Roof 1/2	x2
19. Trolley plank	x1
20. Large stair partition	x2
21. Small stair partition	x2
22. Platform seat	x2

Build Steps


1. Fix end bulk heads to sides squarely and marry subassemblies to produce a box effect.




2. With model inverted, attach the appropriate platforms to bottom edges of bulkheads; with the lip on the platform fitting behind the bulkhead. You may need to trim the edges of the platform to make it fit.
3. Carefully bend the dash panels to fit the curve of the platform, cut to length and fit to platform.



4. Reduce the length of the two ceiling / floor pieces by 3mm each, then solder the two halves together and fix in place.




5. Solder the upper deck sides centrally to the ceiling / floor.
6. Carefully bend the upper vestibules to the shape of the floor, cut to length and fit.



7. Fit the stair partitions.



8. Turn model over and fit the truck sides. You will need to trim the flat section in order for it to fit between the platform ends.
9. Fit the appropriate steps. Fit the life trays to the ends of the truck sides and the life guards under the platforms.



10. Trim the roof halves to the correct length.
11. Solder the two halves of the roof together. Fix the trolley plank to the centre of the roof.

