


KW Trams

KW 002b Leeds 1 - 25 Open Top


Parts




- | | |
|------------------------------|----|
| 1. Tram side 4 window | x2 |
| 2. Truck side | x2 |
| 3. Stairs | x2 |
| 4. Step | x2 |
| 5. Dash panel with headlamp | x2 |
| 6. Resistance box | x2 |
| 7. Upper decency panel sides | x2 |
| 8. Upper decency panel ends | x2 |
| 9. Platform, extended | x2 |
| 10. Upper floor | x1 |
| 11. Lower deck bulkhead | x2 |
| 12. Life guard | x2 |
| 13. Life tray | x2 |
| 14. Controller | x2 |
| 15. Trolley mast | x1 |

Build Steps

1. Fix bulk heads to sides squarely and marry all subassemblies to produce a box effect




2. With model inverted, attach platforms to bottom edges of bulkheads; ensuring the lip is within the body and not on the platform.
3. Carefully bend the dash panels to fit the curve of the platform, trim to length and fit to platform.




4. Fit resistance boxes, the panels of which should face the car's outer side and should fit comfortably between the dash panel and the bulkhead.
5. Fix the ceiling/upper deck floor piece
6. Attach upper deck sides and ends to the floor. File down the corners to make a curve.



7. Fit the stairs



8. Turn model over and attach truck sides to body sides ensuring exact centrality
9. Fix the under-gear ie life guards under the front panels and the life trays attached to the front edge of the truck sides so they do not interfere with the mechanism.



10. Fit the trolley mast and make up a trolley pole from wire

