


KW Trams

KW 002m Aberdeen


Parts




- | | |
|------------------------------------|----|
| 1. Tram side 6 curved top window | x2 |
| 2. Truck side | x2 |
| 3. Stairs | x2 |
| 4. Step | x2 |
| 5. Dash panel with headlamp | x2 |
| 6. Dash panel - shuttered headlamp | x2 |
| 7. Resistance box | x2 |
| 8. Upper decency panel sides | x2 |
| 9. Upper decency panel ends | x2 |
| 10. Platform, extended | x2 |
| 11. Upper floor | x1 |
| 12. Lower deck bulkhead | x2 |
| 13. Life guard | x2 |
| 14. Life tray | x2 |
| 15. Controller | x2 |
| 16. Trolley mast | x1 |
| 17. Destination box | x2 |

Build Steps

1. Fix bulk heads to sides squarely and marry all subassemblies to produce a box effect



2. With model inverted, attach platforms to bottom edges of bulkheads; ensuring the lip is within the body and not on the platform.
3. Carefully bend the chosen dash panels to fit the curve of the platform, trim to length and fit to platform.




4. Fix the ceiling/upper deck floor piece



5. Attach upper deck sides and ends to the floor.



6. Turn model over and attach truck sides to body sides ensuring exact centrality
7. Fix the under-gear ie life guards under the front panels and the life trays attached to the front edge of the truck sides so they do not interfere with the mechanism.



8. Fit the stairs
9. Fit the trolley mast and make up a trolley pole from wire

