


## KW Trams

### KW 002p Cork


#### Parts




- |                                |    |
|--------------------------------|----|
| 1. Tram side curved top window | x2 |
| 2. Truck side                  | x2 |
| 3. Stairs                      | x2 |
| 4. Step                        | x2 |
| 5. Dash panel                  | x2 |
| 6. Resistance box              | x2 |
| 7. Upper decency panel sides   | x2 |
| 8. Upper decency panel ends    | x2 |
| 9. Platform, extended          | x2 |
| 10. Upper floor                | x1 |
| 11. Lower deck bulkhead        | x2 |
| 12. Life guard                 | x2 |
| 13. Life tray                  | x2 |
| 14. Controller                 | x2 |
| 15. Headlamp                   | x2 |
| 16. Trolley mast               | x1 |

#### Build Steps


1. Fit truck sides to sides ensuring they are placed centrally.



2. Fix bulk heads to sides squarely and marry all subassemblies to produce a box effect.




3. With model inverted, attach platforms to bottom edges of bulkheads; ensuring the lip is within the body and not on the platform.
4. Fit the resistance box in the corner of the platform.
5. Carefully bend the chosen dash panels to fit the curve of the platform, trim to length and fit to platform butting up to the resistance box.



6. Fix the ceiling/upper deck floor in place.
7. Attach upper deck sides and ends to the floor.



8. Turn model over and fit the under-gear ie steps, life guards under the front panels and the life trays attached to the front edge of the truck sides so they do not interfere with the mechanism.



9. Fit the stairs
10. Fit the trolley mast and make up a trolley pole from wire

