


KW Trams

KW 002r Mid Yorkshire open top cars


Parts




1.	Tram side 4 window	x2
2.	Truck side	x2
3.	Stairs	x2
4.	Step	x2
5.	Dash panel flat	x2
6.	Resistance box	x2
7.	Upper decency panel sides (tins)	x2
8.	Upper decency panel ends (tins)	x2
9.	Platform, extended	x2
10.	Upper floor	x1
11.	Lower deck bulkhead	x2
12.	Life tray	x2
13.	Life guard	x2
14.	Controller	x2
15.	Destination box	x2
16.	Trolley mast	x1
17.	Light standards	x2

Build Steps


1. Attach truck sides to body sides ensuring exact centrality.




2. Fix bulk heads to sides squarely and marry subassemblies to produce a box effect.




3. With model inverted, attach platforms to bottom edges of bulkheads; ensuring the lip is within the body and not on the platform.
4. Carefully bend the chosen dash panels to fit the curve of the platform, trim to length and fit to platform.



5. Fix the ceiling/upper deck floor piece
6. Attach upper deck sides and ends to the floor.



7. Turn model over and fit the steps and the life trays attached to the front edge of the truck sides so they do not interfere with the mechanism.



8. Fit the stairs
9. Fit the trolley mast and make up a trolley pole from wire.
10. Fit the light standards to the centre of the end panels.

