


KW Trams

KW 006k LCC 106 open top car.


Parts




- | | |
|------------------------------|----|
| 1. Tram side | x2 |
| 2. Truck side | x2 |
| 3. Stairs | x2 |
| 4. Step | x2 |
| 5. Dash panel | x2 |
| 6. Resistance box | x2 |
| 7. Upper decency panel sides | x2 |
| 8. Upper decency panel ends | x2 |
| 9. Platform | x2 |
| 10. Upper floor | x1 |
| 11. Lower deck bulkhead | x2 |
| 12. Life guard | x2 |
| 13. Life tray | x2 |
| 14. Controller | x2 |
| 15. Trolley mast | x1 |
| 16. Destination box | x2 |
| 17. Lamp standards | x2 |
| 18. Long destination boards | x2 |
| 19. Short destination boards | x2 |

Build Steps


1. Attach truck sides to body sides ensuring exact centrality.




2. Fix bulk heads to sides squarely and marry subassemblies to produce a box effect.




3. With model inverted, attach platforms to bottom edges of bulkheads; ensuring the lip is within the body and not on the platform.
4. Carefully bend the dash panels to fit the curve of the platform, trim to length and fit to platform.




5. Fix the ceiling/upper deck floor piece




6. Attach upper deck sides and carefully bend the ends and trim to fit.



7. Turn model over and fit the steps, fix the life guards under the front panels and the life trays attached to the front edge of the truck sides so they do not interfere with the mechanism.



8. Fit the trolley mast and make up a trolley pole from wire. Fit the lamp standards at the top of the stairs.



9. Fit the stairs (unless you wish to paint them first).

