


KW Trams

KW 007a Balcony 3+3 window 4 vent car.


Parts




| | |
|-------------------------|----|
| 1. Tram side 3 window | x2 |
| 2. Truck side | x2 |
| 3. Stairs | x2 |
| 4. Step | x2 |
| 5. Dash panel | x2 |
| 6. Resistance box | x2 |
| 7. Upper sides | x2 |
| 8. Upper bulkheads | x2 |
| 9. Platform | x2 |
| 10. Upper floor | x1 |
| 11. Lower deck bulkhead | x2 |
| 12. Life guard | x2 |
| 13. Life tray | x2 |
| 14. Controller | x2 |
| 15. Balcony ends | x2 |
| 16. Destination box | x2 |
| 17. Roof | x1 |

Build Steps


1. Attach truck sides to body sides ensuring exact centrality.



2. Fix bulk heads to sides squarely and marry subassemblies to produce a box effect.



3. With model inverted, attach platforms to bottom edges of bulkheads; ensuring the lip is within the body and not on the platform.
4. Carefully bend the dash panels to fit the curve of the platform, trim to length and fit to platform.




5. Fix the ceiling/upper deck floor piece




6. Build the upper deck sides & bulkheads on the upper deck floor to form a box.



7. Carefully bend the balcony ends and trim to fit.



8. Turn model over and fit the steps, fix the life guards under the front panels and the life trays attached to the front edge of the truck sides so they do not interfere with the mechanism.



9. Fit the stairs (unless you wish to paint them first).

