


KW Trams

KW 007j West Ham class D car.

Parts




1. Tram side 3 window	x2
2. Truck side	x2
3. Stairs	x2
4. Step	x2
5. Dash panel	x2
6. Resistance box	x2
7. Upper sides	x2
8. Upper bulkheads	x2
9. Platform	x2
10. Upper floor	x1
11. Lower deck bulkhead	x2
12. Life guard	x2
13. Life tray	x2
14. Controller	x2
15. Balcony ends	x2
16. Destination box	x2
17. Roof	x1
18. Under stair gate	x2

Build Steps


1. Attach truck sides to body sides ensuring exact centrality.



2. Fix bulk heads to sides squarely and marry subassemblies to produce a box effect.




3. With model inverted, attach platforms to bottom edges of bulkheads.
4. Carefully bend the dash panels to fit the curve of the platform, leaving enough room for the under stair gate, trim to length and fit to platform.
5. Fit the under stair gate between the dash and the bulkhead.




6. Fix the ceiling/upper deck floor piece




7. Build the upper deck sides & bulkheads on the upper deck floor to form a box.



8. Carefully bend the balcony ends and trim to fit.



9. Turn model over and fit the steps, fix the life guards under the front panels and the life trays attached to the front edge of the truck sides so they do not interfere with the mechanism.



10. Fit the stairs (unless you wish to paint them first).

