


KW Trams

KW 016b Southport California 45


Parts




| | | |
|-----|-------------------|----|
| 1. | Tram side | x2 |
| 2. | Truck side | x2 |
| 3. | Step | x4 |
| 4. | Vestibule | x2 |
| 5. | Platform | x2 |
| 6. | Lower roof half | x2 |
| 7. | Bulkhead | x2 |
| 8. | Life guard | x2 |
| 9. | Life tray | x2 |
| 10. | Controller | x2 |
| 11. | Trolley mast | x1 |
| 12. | Destination board | x2 |
| 13. | Upper roof | x1 |
| 14. | Trolley plank | x1 |
| 15. | Clerestory sides | x2 |
| 16. | Clerestory ends | x2 |
| 17. | Side lifeguards | x4 |

Build Steps


1. Fix bulk heads to sides squarely and marry subassemblies to produce a box effect.




2. Attach truck sides to body sides ensuring exact centrality.



3. With model inverted, attach platforms to bottom edges of bulkheads; ensuring the lip is within the body and not on the platform. You will need to trim the sides of the platforms so that they fit against the truck sides.
4. Solder the two halves of the roof together and fit.
5. Carefully bend the vestibules to fit the curve of the platform and fit to platform.
6. Turn model over and fix the end life guards under the front panels and the life trays attached to the front edge of the truck sides so they do not interfere with the mechanism.
7. Fit the steps to the sides of the platforms, then fit the side lifeguards behind the steps between the front lifeguard and the life tray.



8. Fit the clerestory sides so that they fit just inside the roof. Then fit the clerestory ends.



9. Fit the upper roof centrally to the top, and the trolley plank centrally to that.
10. Fit the trolley mast and make up a trolley pole from wire
11. Fit the destination boxes to the ends of the upper roof.

