


KW Trams

KW 022c Liverpool Twin Staircase cars batch 2 583-605 Later

Parts




Contents


| | | |
|-----|-----------------------|----|
| 1. | Tram side | x2 |
| 2. | Truck side | x2 |
| 3. | Stairs | x2 |
| 4. | Long step | x2 |
| 5. | Short step | x2 |
| 6. | Dash panel | x2 |
| 7. | Upper sides | x2 |
| 8. | Upper vestibules | x2 |
| 9. | Long platform | x2 |
| 10. | Upper floor 1/2 | x2 |
| 11. | Lower deck bulkhead | x2 |
| 12. | Life guard | x2 |
| 13. | Life tray | x2 |
| 14. | Controller | x2 |
| 15. | Short platform | x2 |
| 16. | Handbrake | x2 |
| 17. | Handbrake wheel | x2 |
| 18. | Roof 1/2 | x2 |
| 19. | Trolley plank | x1 |
| 20. | Large stair partition | x2 |
| 21. | Small stair partition | x2 |
| 22. | Platform seat | x2 |

Build Steps

1. Fix end bulk heads to sides squarely and marry subassemblies to produce a box effect.




2. With model inverted, attach the appropriate platforms to bottom edges of bulkheads; with the lip on the platform fitting behind the bulkhead. You may need to trim the edges of the platform to make it fit.
3. Carefully bend the dash panels to fit the curve of the platform, cut to length and fit to platform.




4. Solder the two halves of the ceiling / floor together and fix in place.




5. Solder the upper deck sides centrally to the ceiling / floor.
6. Carefully bend the upper vestibules to the shape of the floor, cut to length and fit.



7. Fit the stair partitions.



8. Turn model over and fit the truck sides. You will need to trim the flat section in order for it to fit between the platform ends.
9. Fit the appropriate steps. Fit the life trays to the ends of the truck sides and the life guards under the platforms.



10. Trim the roof halves to the correct length.
11. Solder the two halves of the roof together. Fix the trolley plank to the centre of the roof.

