


KW Trams

KW 047 Birmingham 361-450


Parts



- | | |
|----------------------------------|----|
| 1. Roof | x1 |
| 2. Floor / ceiling | x1 |
| 3. Upper side | x2 |
| 4. Lower side | x2 |
| 5. Truck side | x2 |
| 6. Platform | x2 |
| 7. Balcony ends | x2 |
| 8. Balcony seats | x2 |
| 9. Stair partitions | x2 |
| 10. Upper bulkhead | x2 |
| 11. Lower bulkhead | x2 |
| 12. Lifetray | x2 |
| 13. Destination number box | x2 |
| 14. Trolley plank | x1 |
| 15. Resistance box | x2 |
| 16. Upper deck used ticket boxes | x2 |
| 17. Side destination boxes | x2 |
| 18. Stairs | x2 |
| 19. Controller | x2 |
| 20. Handbrake | x2 |
| 21. Front lifeguard | x2 |
| 22. Side lifeguard | x2 |
| 23. Vestibule | x2 |
| 24. Step | x2 |

Build Steps


1. If modelling cars 401-450, remove the track brake from the truck side.
2. Attach truck sides to body sides ensuring exact centrality.




3. Fix bulk heads to sides squarely and marry subassemblies to produce a box effect.




4. Gently bend the vestibules to fit the shape of the platform front and fit.
5. Fit the platform / vestibule to the bulkhead.



6. Fix the ceiling/upper deck floor piece.



7. Fix upper bulkheads to upper sides and marry subassemblies to produce a box effect.




8. Fit upper deck to centre of floor.



9. Carefully bend the balcony ends to shape, cut to length and fit.



10. Turn model over and fit the steps and the life trays attached to the front edge of the truck sides so they do not interfere with the mechanism. Fit the side and front lifeguards.



11. Solder the two halves of the roof together and fit the trolley plank to the centre.

