


KW Trams

KW 048 Birmingham Works 8

Parts




- | | |
|--------------------------|----|
| 1. Roof | x1 |
| 2. Side | x2 |
| 3. Truck side | x2 |
| 4. Platform | x2 |
| 5. Bulkhead | x2 |
| 6. Lifetray | x2 |
| 7. Trolley plank | x1 |
| 8. Resistance box | x2 |
| 9. Controller | x2 |
| 10. Handbrake | x2 |
| 11. Front lifeguard | x2 |
| 12. Side lifeguard | x2 |
| 13. Short side lifeguard | x2 |
| 14. Dash | x2 |
| 15. Vestibule | x2 |
| 16. Vestibule extension | x2 |
| 17. Step | x2 |
| 18. Water tank | x4 |
| 19. Water tank back | x4 |

Build Steps


1. Attach truck sides to body sides ensuring exact centrality. You will need to trim the upper section of the truck side to make it fit inside the body side.




2. Fix bulk heads to sides squarely and marry subassemblies to produce a box effect.



3. With model inverted, attach platforms to bottom edges of bulkheads; ensuring the lip is within the body and not on the platform.
4. Gently bend the dash panels to fit the shape of the platform front, cut to length and fit to platform.
5. Bend the vestibule to shape and fit to the top edge of the dash. Fit the vestibule extension.



6. Turn model over and fit the steps and the life trays attached to the front edge of the truck sides so they do not interfere with the mechanism. Fit the side and front lifeguards.



7. Fit the trolley plank to the centre of the roof.



8. Fit the roof and make up a trolley pole from wire.

