


# KW Trams

## **KW 107 Bristol.**

### Parts




- |                                |    |
|--------------------------------|----|
| 1. 3 window tram side          | x2 |
| 2. Bulkhead                    | x2 |
| 3. Platform                    | x2 |
| 4. Truck side                  | x2 |
| 5. Stairs                      | x2 |
| 6. Dash panels                 | x2 |
| 7. Resistance box              | x1 |
| 8. Controller                  | x2 |
| 9. Handbrake                   | x2 |
| 10. Middle ceiling/floor piece | x1 |
| 11. Ceiling / floor ends       | x2 |
| 12. Life Guard                 | x2 |
| 13. Life tray                  | x2 |
| 14. Destination box            | x2 |
| 15. Upper deck decency panel   | x3 |
| 16. Steps                      | x2 |
| 17. Trolley mast               | x1 |
| 18. Canopy switch              | x1 |
| 19. Headlamps                  | x2 |
| 20. Driver                     | x1 |
| 21. Conductor                  | x1 |
| 22. Lower deck seats           | x4 |

### Build Steps


1. Attach the truck sides centrally to the saloon sides.




2. Adjust the shape of the lower side of the bulkhead or the body side so that they fit together properly.
3. Produce the lower saloon box of 2 lower sides and 2 bulk heads by assembly on a flat surface in the upside down position




4. Attach the platforms centrally under the bulkheads with the raised sections flush with the back of the bulkhead.
5. Fit the curved dash panels to the platform – it will need to be trimmed to fit. Fit the headlamps to the centre of the dash.




6. Fix the two ends of the ceiling / floor to the middle and then fit to the saloon.




7. Fit two of the open top sides to the ceiling / floor. Cut the third in half and bend so that it fits between the end of the side and the end of the top by the stairs.



8. Turn model over to fit the steps, lifeguards and life trays.



9. Fit the trolley mast to the middle of the upper floor.



10. Fit the stairs unless you wish to paint them first. Trim the height of the stairs to make them fit.

